

Read me.txt

°²x°ÈµÃ÷f°

1;Ç´ONI¹«È¾¹Ù·½ÍðÕ¾iA00Çý¶³iDòNI-VISA
5.3°æ±¾f-IA00IA¼pvisa530runtime.exe f`0¼100Mf0»ò
visa530full.exe f`0¼700Mf0;f
2;Ç0ÈÐÐNI-VISA 5.3f-°²x°Çý¶³iDò;f
3;Ç0ÈÐÐ²Ç°²x°ÉiI»»úÓ!ÓÃÈi¼p;f
4;Ç0§³Ö²Ùx÷iµi³f° windows 8 32-bit/8 64-bit/7 64-bit/7
32-bit/Vista 64-bit/Vista 32-bit/XP/Server 2008 R2 64-bit/Server
2003 R2 32-bitXP;f

Setup Explanation:

- 1) Download the driver "NI-VISA" Version 5.3 from NI websitef-you can download file "visa530runtime.exe"(about 100M) or "visa530full.exe"(about 700M).
- 2) Execute the file to install the driver programf`visa 3.5f0.
- 3) Execute and install the application software.
- 4) Support OS: windows 8 32-bit/8 64-bit/7 64-bit/7 32-bit/Vista 64-bit/Vista 32-bit/XP/Server 2008 R2 64-bit/Server 2003 R2 32-bitXP opertion system.